

5.6 Bus Connectors

Purpose of the Bus Connector

The bus connector is used to connect the PROFIBUS-DP bus cable to the MPI or PROFIBUS-DP interface. In this way, you establish the connection to other nodes.

There are two different bus connectors:

- Bus connector without PG connector

6ES7972-0BA12-0XA06

6ES7972-0BA41-0XA0

6ES7972-0BA50-0XA0

6ES7972-0BA60-0XA0

6ES7972-0BA30-0XA0

- Bus connector with PG connector

6ES7972-0BB12-0XA0

6ES7972-0BB41-0XA0

6ES7972-0BB50-0XA0

6ES7972-0BB60-0XA0

Appearance (6ES7972-0B.20 ...)




Figure 5-11 Bus connector